

CHILDREN SHALL NOT PLAY WITH THE APPLIANCE. APPLIANCE IN A SAFE WAY AND UNDERSTAND THE HAZARDS INVOLVED BEEN GIVEN SUPERVISION OR INSTRUCTION CONCERNING USE OF THE AND ABOVE AND PERSONS WITH REDUCED PHYSICAL, SENSORY OR MENTAL CAUTION:-THIS APPLIANCE CAN BE USED BY CHILDREN AGED FROM 8 YEARS CAPABILITIES OR LACK OF EXPERIENCE AND KNOWLEDGE IF THEY HAVE

WITHOUT SUPERVISION CLEANING AND USER MAINTENANCE SHALL NOT BE MADE BY CHILDREN

BATH OR SHOWER. THIS APPLIANCE MUST BE FIXED OUT OF REACH OF A PERSON TAKING A



OF AT LEAST 3mm.

TO USE

MOUNTING INSTRUCTIONS

CARE SHOULD BE TAKEN THAT SINGLE INSULATED CONDUCTORS CANNOT COME INTO CONTACT WITH THE MOUNTING SURFACE.

THIS HAND DRYER MUST BE FIXED OUT OF REACH OF A PERSON TAKING A BATH OR SHOWER

ALWAYS ENSURE THAT THE INSTALLATION CONFORMS TO THE CURRENT EDITION OF THE IEE WIRING REGULATIONS, BS7671(UK) OR THE APPROPRIATE STANDARDS IN YOUR COUNTRY. ENSURE THAT THE UNIT IS SEPARATELY FUSED WITH A SUITABLY RATED FUSE AND THAT IT IS CONNECTED

INSTALLATION INSTRUCTIONS

TO THE SUPPLY WITH A DOUBLE POLE ISOLATING SWITCH HAVING A CONTACT SEPARATION

- PLACE HANDS UNDER HAND DRYER.
- 4 6 4
- FROM THE DRYER
- THE DRYER WILL STOP AUTOMATICALLY



- AUTOMATICALLY START.
 ONCE DRY REMOVE HANDS THE HAND DRYER WILL
- AFTER INSTALLATION OR SERVICING, UNITS MUST BE CHECKED, AND ONLY LEFT WHEN ELECTRICALLY AND MECHANICALLY SAFE

b) 1.3 METRES ABOVE FLOOR WHERE AVERAGE AGE OF USER IS BELOW 16 YEARS THIS HAND DRYER MUST NOT BE MOUNTED ABOVE SHELVES, SINKS OR RADIATORS TO ENSURE EASE OF INSTALLATION AND SUBSEQUENT MAINTENANCE, THE HORIZONTAL DISTANCE TO ANY ADJACENT WALL SHOULD NOT BE LESS THAT 0.2 METRES

RECOMMENDED FIXING HEIGHTS TO TOP OF UNIT ARE AS FOLLOWS:-

1.5 METRES ABOVE FLOOR FOR NORMAL USE

UNIT MUST BE FIXED TO A SOLID SUPPORTING WALL. SEE OVERLEAF FOR MOUNTING HOLE TEMPLATE.

SUPPLY VOLTAGE AND FREQUENCY SERVICING THE HAND DRYER

INTERVALS AS EXPERIENCE DICTATES THE MINIMUM SERVICE PERIOD FOR THE DRYER SHOULD BE EVERY 3 MONTHS OR MORE FREQUEN When ordering replacement modules always quote SERIAL NO., MODEL/SERIES, ELECTRICAL

ISOLATE THE UNIT FROM THE ELECTRICITY SUPPLY BEFORE SERVICING. REMOVE DUST, FLUFF AND ANY OTHER BUILD UP OF FOREIGN MATTER FROM INLET AND OUTLET GRILLE AREAS

WARNING : BEFORE OBTAINING ACCESS TO TERMINALS ALL SUPPLY CIRCUITS MUST BE DISCONNECTED.

Nederland authorisedrep@andaproducts.nl Bedrijvenweg 17 7442 CX Nijverdal EU Authorised Representative: Anda Products PO BOX 1285, CRAWLEY, UK, RH10 0LY

C15, C15, C15/S - 1250W C10 1000W C20, C20SS - 1800W

220-240V~ 50Hz, Class I, IP22



Correct Disposal of this product

responsibly to promote the sustainable reuse of material for environmental safe recycling resources. To return your used device, please use health from uncontrolled waste disposal, recycle it disposed with other household wastes throughout the EU the product was purchased. They can take this product return and collection systems or contact the retailer where To prevent possible harm to the environment or human This marking indicates that this product should not be


The hand dryer is Guaranteed for two years from the date of purchase against faulty

or at the Manufacturers option a) has been installed and used materials or workmanship.
In the event of any part being found to be defective, the hand dryer will be repaired. replaced, without charge, provided that the hand dryer: in accordance with the instructions given with each

- b) has not been connected to an unsuitable electrical supply. (Correct electricity supply requirements are stated on the units rating label)
- has not been subjected to mis-use, neglect or damage
- 000 has been properly serviced in accordance with the instructions given has not been modified or repaired by any person not authorised by the Manufacturer

This guarantee excludes labour after an initial 12 month period.





FAULT DIAGNOSIS CHART